



NOTES:

- 1). DISCHARGE ALL TEMPORARY SLOPE DRAINS ONTO A STABILIZED OUTFALL AND THEN INTO A SEDIMENT TRAPPING DEVICE.
- 2). USE TEMPORARY SLOPE DRAINS AT THE TOP OF FILL SLOPES AS EMBANKMENT IS CONSTRUCTED TO PREVENT EXCESSIVE EROSION UNTIL SHOULDERS ARE CONSTRUCTED AND THE SLOPES ARE SEEDING AS PER SPECIFICATIONS.
- 3). FOR ALL TEMPORARY SLOPE DRAINS, USE A MINIMUM OF 3 HOLD DOWN STAKES SPACED EVENLY THROUGHOUT THE WHOLE LENGTH BEGINNING AT THE PIPE OUTLET INTO THE R-4 RIPRAP.



Andrew Shott
 ENGINEERING SUPPORT
 12/22/2023
 DATE
RECOMMENDED

TEMPORARY SLOPE DRAIN

STANDARD NO. E-10 (2024) SHT. 1 OF 1

REVIEWED
 DEPUTY DIRECTOR - DESIGN
 22 December 2023
 DATE

APPROVED
 CHIEF ENGINEER
 01/11/2024
 DATE