



- NOTES:**
- 1). INSTALL SANDBAG DIKE IN UPSTREAM LOCATION FIRST.
 - 2). CONSTRUCT SANDBAG DIKE SUCH THAT THE HEIGHT IS 1'-0" ABOVE THE PEAK ELEVATION OF THE 1 YEAR STORM, OR 1'-0" BELOW THE TOP OF THE BANK, WHICHEVER IS LESS. SEE PLANS FOR MORE INFORMATION.
 - 3). CONSTRUCT WEIR SUCH THAT IT WILL PASS A 1 YEAR STORM EVENT PEAK FLOW. SEE PLANS FOR MORE INFORMATION.
 - 4). SIZE THE PIPE SUCH THAT IT WILL ALLOW PASSAGE OF THE STREAM BASE FLOW.

	<i>Andrew Shott</i> ENGINEERING SUPPORT DATE 12/22/2023	SANDBAG DIKE			REVIEWED <i>[Signature]</i> DEPUTY DIRECTOR - DESIGN 22 December 2023 DATE
	RECOMMENDED	STANDARD NO. E-15 (2024)	SHT. 1 OF 1	APPROVED <i>[Signature]</i> CHIEF ENGINEER 01/11/2024 DATE	