





NOTES:

1). USE KEYWAY WHEN HOOK BOLT, TIE BAR, OR W BOLT IS NOT USED.

2). PROVIDE TIE BARS FOR TYPE B PATCHES PLACED ADJACENT TO CONCRETE. DO NOT INSTALL TIE BARS ON TYPE A PATCHES.

DelDOT=	İ
---------	---

andrew Shot	12/22/2023	LONGITUDINAL CONSTRUCTION JOINT DETAIL						
ERING SUPPORT	DATE							
RECOMMENDED		STANDARD NO.	P-2 (2024)	SHT.	3	OF	6	

REVIEWED

APPROVED

DIRECTOR - DESIGN

CHIEF ENGINEER

22 December 2023

01/11/2024 DATE