

NOTES:

- 1). DIG BASE OF PLANTING PIT A MINIMUM OF TWO AND A MAXIMUM OF THREE TIMES THE SIZE OF THE ROOT BALL.
- 2). INSTALL SHRUBS IN MASSES OF NO LESS THAN 3 PLANTS. A MINIMUM OF 3'-0" IS REQUIRED FROM MIDDLE OF SHRUB TO ANY PERMANENT STRUCTURE (I.E. CURB, SIDEWALK, BUILDING, ETC...)

 3). SHRUB PRUNING IS TO BE PERFORMED BY AN I.S.A. CERTIFIED ARBORIST, CERTIFIED NURSERY
- PROFESSIONAL, OR UNDER THE DIRECTION THEREOF. DO NOT HEAVILY PRUNE SHRUBS AT PLANTING.
- 4). HAND DIG AUGERED HOLES TO FINAL WIDTH AND DEPTH TO ELIMINATE GLAZING.
- 5). MULCH ALL SHRUB MASSES IN ONE CONTINUOUS BED.

ROADSIDE SHRUB PLANTING DETAIL



andrew Shot	12/22/2023	PLANTING DETAILS						REVIEWED		
RECOMMENDE	DATE	STANDARD NO.	L-1 (2024)	SHT.	1	OF	4		APPROVED	

DEPUTY DIRECTOR - DESIGN

CHIEF ENGINEER

22 December 2023

DATE

01/11/2024 DATE